

## C&B SEEN PROGRAMMABLE REMOTE DIPSWITCH QUICKSTART INSTRUCTIONS



When you first receive the kit the remote will already have been 'Paired' with the lamp – if need be a new remote can be paired later.

Your remote switch consists of 3 separate components:

- 1, The bar mounted cradle
2. The remote switch itself
3. A snap-on cover (pic above right shows cover on)

The cradle may be mounted to the bars using either the supplied O rings or, for those of you who do not want the hassle of using the O rings, you might prefer using a small cable tie. The switch itself slides into the cradle and can be positioned to suit. The cover should be used if the light and the remote are ever packed together to avoid accidental activation of the light through pressure on the Remote buttons.

The two buttons are designated with symbols – a [ ] for Up, and a O for Down. To turn on the light hold the [ ] button in for 1.5 secs.

Clicking on the [ ] button will cycle the lamp through Low-Medium-High modes. A click on the O button will activate the Pulse mode.

To return to normal beam from pulse just click on the [ ] button.

To turn off the light hold the [ ] button in for 1.5 seconds will switch the lamp into Standby mode. This mode allows the lamp to remain attached to the battery pack but with 0V drain on the battery. To exit Standby mode hold the [ ] button for 1.5 seconds which will turn the light back on. Disconnect lamp from battery to switch to permanently Off.

Further more detailed instructions will be published shortly on the website explaining how to use the Programmable features of the Lamp/Remote combination. This includes how to 'Pair' a new Remote, how to change the factory preset Mode power levels, and how to use the Remote to allow you to fine tune your light settings in 10% increments whilst riding.