

TECHNICAL ASPECTS OF LIGHT AND REMOTE BUTTON PROGRAMMING FEATURES FOR THE CABS-06 AND CABS-07 SERIES LIGHTS WITH REMOTE

FACTORY DEFAULT SETTINGS FOR LAMP POWER MODES

POWER LEVEL	FACTORY SET	WATTS	EST RUN TIME (HRS)
10		20	1.9
9		17.9	2.1
8	HIGH	15.7	2.4
7		13.6	2.8
6		11.4	3.3
5		9.3	4.1
4		7.1	5.3
3	MEDIUM	5	7.6
2		2.8	13.5
1	LOW	0.6	58.1

You may also choose to ride In Programming mode by entering Programming Mode as above and then by using single clicks of the Square and Round buttons to increase or decrease power to lamp in 10% increments.